

Configuration Guide

Ethernet-Switching-Configuration - MS400995M

MICROSENS GmbH & Co. KG
Kueferstr. 16
59067 Hamm/Germany
Tel. +49 2381 9452-0
FAX +49 2381 9452-100
E-Mail info@microsens.de
Web www.microsens.de

Table of Contents

- 1. Config Guide 1
 - 1.1. Copyright Statement 1
 - 1.2. Exemption Statement 1
 - 1.3. Preface 1
 - 1.4. Audience 1
 - 1.5. Obtaining Technical Assistance 1
 - 1.6. Related Documents 1
 - 1.7. Conventions 2
 - 1.8. Symbols 2

Chapter 1. Config Guide

1.1. Copyright Statement

Microsens Networks©2020 Microsens Networks reserves all copyrights of this document. Any reproduction, excerption, backup, modification, transmission, translation or commercial use of this document or any portion of this document, in any form or by any means, without the prior written consent of Microsens Networks is prohibited.

1.2. Exemption Statement

This document is provided "as is". The contents of this document are subject to change without any notice. Please obtain the latest information through the Microsens Networks website. Microsens Networks endeavors to ensure content accuracy and will not shoulder any responsibility for losses and damages caused due to content omissions, inaccuracies or errors.

1.3. Preface

Thank you for using our products. This manual matches the RGOS Release 12.1(2)B0102.

1.4. Audience

This manual is intended for: * Network engineers * Technical support and servicing engineers * Network administrators

1.5. Obtaining Technical Assistance

- Microsens Networks Website: <https://www.Microsensnetworks.com/>
- Technical Support Website: <https://Microsensnetworks.com/support>
- Case Portal: <https://caseportal.Microsensnetworks.com>
- Community: <https://community.Microsensnetworks.com>
- Technical Support Email: service_rj@Microsensnetworks.com
- Skype: [service_rj@Microsensnetworks.com](https://www.skype.com/en/contacts/microsens-networks/)

1.6. Related Documents

Documents	Description
Command Reference	Describes the related configuration commands, including command modes, parameter descriptions, usage guides, and related examples.

Hardware Installation and Reference Guide	Describes the functional and physical features and provides the device installation steps, hardware troubleshooting, module technical specifications, and specifications and usage guidelines for cables and connectors.
---	--

1.7. Conventions

This manual uses the following conventions:

Convention	Description
boldface font	Commands, command options, and keywords are in boldface .
<i>italic</i> font	Arguments for which you supply values are in <i>italics</i> .
[]	Elements in square brackets are optional.
{ x y z }	Alternative keywords are grouped in braces and separated by vertical bars.
[x y z]	Optional alternative keywords are grouped in brackets and separated by vertical bars.

1.8. Symbols



Means reader take note. Notes contain helpful suggestions or references.



Means reader be careful. In this situation, you might do something that could result in equipment damage or loss of data.

Our [General Terms and Conditions of Sale \(GTCS\)](https://www.microsens.com/fileadmin/files/downloads/Impressum/MICROSENS_AVB_EN.pdf) apply to all orders (see https://www.microsens.com/fileadmin/files/downloads/Impressum/MICROSENS_AVB_EN.pdf).

Disclaimer

All information in this document is provided 'as is' and is subject to change without notice.

MICROSENS GmbH & Co. KG disclaims any liability for the correctness, completeness or quality of the information provided, fitness for a particular purpose or ensuing damage.

Any product names mentioned herein may be trademarks and/or registered trademarks of their respective owners.

©2024 MICROSENS GmbH & Co. KG, Kueferstr. 16, 59067 Hamm, Germany.

All rights reserved. This document in whole or in part may not be duplicated, reproduced, stored or retransmitted without prior written permission of MICROSENS GmbH & Co. KG.

Document ID: CONF-EN-22003_MS400995M-Configuration_Guide_v1.2